

For The ON-THE-GO Pet™

INSTRUCTION MANUAL VIEW 360 STROLLER, BOOSTER AND CARRIER TRAVEL SYSTEM

PG8140NZ



To see our full line of products, visit us online at: www.petgearinc.com

CUSTOMER SERVICE HELP DESK

customerservice@petgearinc.com

Toll-Free 877-752-9123 - Eastern Standard Time 8am-3pm, Monday through Friday

PARTS LIST

Check that you have all the parts shown BEFORE assembling your product. If any parts are missing, call Customer Service.



Stroller



2-Front Wheels



Cup Holder




2-Rear Wheels

UNFOLDING THE STROLLER

Step 1. Spread handle (A) and seat apart until the frame clicks and locks on both sides.

Step 2. Stroller should look like this when unfolded.



TO ASSEMBLE REAR WHEELS TO FRAME

Step 1. Push rear wheel onto frame until it clicks and locks into place on both sides.

TO ASSEMBLE FRONT WHEELS

Step 1. Push front wheels onto stroller tubing until steel pin locks (pops out).


Step 2. Release locking lever by pushing lever down so wheel can swivel 360° while strolling.



INSTRUCTIONS FOR BRAKE USE

Apply brake lever by pushing down with toe. Ensure brakes are applied when parking stroller. Release by lifting brake lever with toe.

WARNING: Never leave your stroller parked without applying brakes.







Brake is applied when lever is down.

Brake is not applied when lever is up.

TO USE FRONT WHEEL LOCKING MECHANISM


Step 1. To engage the front wheel locking mechanism so that the front wheel does not swivel (best when the stroller is used for fast walking or running) pull tab up.

Step 2. To disengage the locking mechanism so that the front wheel swivels (for easy steering) push tab down.



TO ASSEMBLE CUP HOLDER

Step 1. Snap the cup holder over plastic bolt and push downwards to lock.



USING CARRIER WITH STROLLER

Place carrier onto stroller frame and lock latch downwards on both sides to secure.




CARRIER / BOOSTER PARTS LIST

Check that you have all the parts shown BEFORE assembling your product. If any parts are missing, call Customer Service.




Unfold metal wires on the bottom of the View 360 Carrier.







Push button to open carrier.



ASSEMBLY INSTRUCTIONS FOR BOOSTER BASE




SECURING BOOSTER SEAT FRAME



USING BOOSTER SEAT

Place carrier onto base and lock latch downwards on both sides to secure carrier to base.



Push latch down to lock.



TO USE CARRIER AS CAR SEAT WITHOUT BOOSTER BASE



Place seat belt through the seat belt strap located on the back of car seat/carrier.

Click seat belt into place.



Never leave your pet unattended in your car. Always use a pet harness.

LOOKING AFTER YOUR STROLLER

- Always store product in a clean, dry place.
- Not recommended for use on the beach.
- Do not put heavy items on top of the stroller.
- Clean frame by wiping with a lightly oiled cloth.
- Do not use detergent or abrasives. Spot clean fabric with dry cleaning fluid or mild soap and warm water.
- To ensure easy maneuverability and to minimize wear and tear, (especially wheels, axles, and swivels), keep all moving parts clean and lubricated with WD40[®] or light machine oil.
- NOTE: Do not lubricate brake components or swivel locks.
- Regularly check stroller for loose parts. These should be tightened or replaced.

WHEEL MAINTENANCE

- To clean and lubricate front and rear wheels, push out locking lever under wheel housing to release rear wheel.
- To ensure ease of maneuverability and to minimize wear and tear, keep all moving parts clean and lubricated with WD40[®] or light machine oil.
- Push wheel sets back on until they click and lock in position; pull on wheel housings to ensure they are secure.
- Push stroller back and forth and rotate swivels around to work in lubricant.
- Clean the rear wheel assembly and the rest of the frame with warm, soapy water; clean off with warm water and dry thoroughly.
- NOTE: Do not lubricate brake components or swivel locks.

▲ WARNING!

FOR PETS ONLY.

Not intended to be used as a restraining device for aggressive or dangerous animals that dig, chew or paw aggressively. Do not leave your pet unattended. **PET GEAR** is not liable for any damage caused by aggressive, destructive, immature or untrained animals. Do not use near an open or exposed flame. Failure to follow these warnings and the instructions could result in serious injury or death.

- Do not carry additional bags, goods, or accessories in or on stroller except as recommended in the manufacturer's instructions.
- Recommended use of an approved safety restraint correctly fitted and adjusted.
- Do not leave pet unsupervised in stroller.
- Before making adjustments to stroller ensure that pet's body is clear of any moving parts.
- This stroller is designed for one pet only.
- Do not hang bags from handles as this may cause the product to become unstable.
- Do not use on escalator or stairs; fold stroller and carry.
- Put on brake whenever you park the stroller.
- Ensure stroller is completely erected and check that all locks are engaged before placing pet in stroller.
- Do not overload as stroller may become unstable; maximum weight of pet using this stroller not to exceed 45 lbs.
- Any goods carried in the basket not to exceed 6 lbs.

REPLACEMENT PARTS

Use only **PET GEAR** replacement parts. Please have your model number ready before calling. You can also request parts: <u>http://www.petgearinc.com/main.asp?sel=2</u>



192 Sheldon Avenue • West Rutland, VT 05777 • 877-752-9123 • www.petgearinc.com