




**PET GEAR™**

# MODEL:PG8100ST

## PARTS LIST

- A** FOLDING LOCK \_\_\_\_\_
- B** HANDLE \_\_\_\_\_
- C** BRAKE LEVERS \_\_\_\_\_
- D** SWIVEL WHEELS \_\_\_\_\_
- E** BASKET \_\_\_\_\_
- F** UTILITIES TRAY \_\_\_\_\_
- G** MAIN FRAME LOCK RELEASE \_\_\_\_\_
- H** SECOND FRAME LOCK RELEASE \_\_\_\_\_
- I** CANOPY \_\_\_\_\_
- J** CANOPY WINDOW \_\_\_\_\_



Illustrations are representative only.  
Design and style may vary.


## INSTRUCTIONS

**PLEASE READ THESE INSTRUCTIONS CAREFULLY**


Your stroller is designed to be practical, easy to use, and comfortable for your pet.

- The weight of the pet using this stroller should not exceed 33 lbs.


# Parts List




**Stroller Frame**



**Front Wheel  
Assembly (2)**



**Back Tray**



**Rear Wheels (2)**



**Rear Axle Assemblies**



**Washer (2)**



**Cotter Pin (2)**



**Hub Cap (2)**

# WARNING

- For pets only.
- Do not carry additional bags, goods, or accessories in or on stroller except as recommended in the manufacturer's instructions.
- Recommended use of an approved safety restraint correctly fitted and adjusted.
- Do not leave pet unsupervised in stroller.
- Before making adjustments to stroller ensure that pet's body is clear of any moving parts.
- This stroller is designed for one pet only.
- Do not hang bags from handles as this may cause the product to become unstable.
- Do not use on escalator or stairs. Fold stroller and carry.
- Put on brake whenever you park the stroller.
- Ensure stroller is completely erected and check all locks are engaged before placing pet in stroller.
- Do not overload as stroller may become unstable. Maximum weight of pet using this stroller should not exceed 33 lbs.
- Any goods carried in the basket not to exceed 6 lbs.
- Do not use near an open fire or exposed flame.


# WHEEL MAINTENANCE

- To clean and lubricate front and rear wheels, push out locking lever under wheel housing to release rear wheel.
- To ensure ease of maneuverability and to minimize wear and tear, keep all moving parts clean and lubricated with WD40 or light machine oil.
- Push wheel sets back on until they click and lock in position. Pull on wheel housings to ensure they are secure.
- Push stroller back and forth and rotate swivels around to work in lubricant.
- Clean the rear wheel assembly and the rest of the frame with warm soapy water; clean off with warm water and dry thoroughly.

NOTE: Do not lubricate brake components.


# ASSEMBLY INSTRUCTIONS

## UNFOLD STROLLER



- Release folding lock (A).
- Spread handle (B) and seat apart until the frame clicks and locks on both sides.
- Ensure that the stroller is locked in on both sides before using.

## ASSEMBLE REAR WHEELS TO AXLE




## ASSEMBLE REAR WHEELS TO AXLE

NOTE: For products with wheels not assembled.


- Slide wheel assembly onto axle.
- Slide washer onto axle.
- Fit straight part of cotter pin through hole on axle.
- Line up each of the tabs in the hub cap with the slots in the wheel, snap hub cap into place. (see page 3)
- Fit cover to collet by firmly pressing the cover into place.
- Push wheel hubcap onto the wheel hub and make sure that the securing lugs correctly locate into mating slots in wheel hub.
- Repeat for other side.

## ASSEMBLE REAR AXLE TO FRAME



- Turn stroller over.
  - Position rear axle assembly as shown.
  - Push rear axle onto frame until it clicks and locks into place on both sides.
- NOTE: Pull down firmly on the brackets to be sure they are securely attached to the stroller's rear legs.



## ASSEMBLE FRONT WHEELS



- Place front wheel unit on leg with locking lever pointing downward.
- Press locking lever and slide swivel housing onto front leg.
- Release locking lever.

## FOLD

- Before folding the stroller, close the canopy.
- Slide second frame lock release (H) and squeeze main frame lock release (G).
- Allow the handle to lower toward the rear wheels.
- When closed push folding lock (A) onto catch.



# INSTRUCTIONS FOR USE

- Spread the **canopy** apart to the open position.
- Ensure the **canopy** is closed before folding the stroller.



- Apply brake lever (C) by pushing down with toe.
- Ensure **brakes** are applied when parking stroller.
- Release by lifting brake lever with toe.

WARNING: Never leave your stroller parked without applying **brakes**.

## FEATURES

- Suitable for pets up to 33 lbs
- Lightweight
- Fully lined canopy with viewing window
- Generous shopping basket
- Easy to fold

## LOOKING AFTER YOUR STROLLER

- Always store product in a clean dry place.
- Not recommended for use on the beach.
- Do not put heavy items on top of the stroller.
- Clean frame by wiping with a lightly oiled cloth.
- Do not use detergent or abrasives. Spot clean fabric with drycleaning fluid or mild soap and warm water.
- To ensure easy maneuverability and to minimize wear and tear (especially wheels, axles, and swivels) keep all moving parts clean and lubricated with WD40 or light machine oil.
- NOTE: Do not lubricate brake components or swivel locks.
- Regularly check stroller for loose parts. These should be tightened or replaced.



**PET GEAR™**

**PO Box 99  
West Rutland, VT 05777  
877-752-9123  
WWW.PETGEARINC.COM**